



# SAF-AIR CROSS REFERENCE CHART\*

SAF-AIR	CURTIS DIRECT REPLACEMENT	THREAD SIZE
CAV-110	CCA-1800	1/8 NPT   TSO-C76
CAV-160	CCA-1900	1/4 NPT   TSO-C76
CAV-170	CCA-2100	7/16"-20   TSO-C76
CAV-180	CCA-2000	3/8"-24   TSO-C76
1250	CCA-1550   PUSH TO OPEN	1/8 NPT   TSO-C76
SA53S	CCA-53	7/16"-20   TSO-C76
2500	CCA-1300   SPIRAL TO OPEN	1/4 NPT   TSO-C76
F75	CCA-75	3/4"-20   TSO-C76 Pending
4375	CCA-4300	7/16"-20   TSO-C76
4375H	CCA-5400	7/16"-20   TSO-C76
SA14	CCA-2600	1/4 NPT   TSO-C76
SA18	CCA-2500	1/8 NPT   TSO-C76
SA32	CCA-2700	3/8"-24   TSO-C76
SA72	CCA-2800	7/16"-20   TSO-C76
SA82	CCA-2900	1/2"-20   TSO-C76
SA187	CCA-2500	1/8 NPT   TSO-C76
C500	CCA-3400	BLADDER   TSO-C76
P3750	CCA-1650   PUSH TO OPEN	3/8 NPT   TSO-C76
	CCA-1350   SPIRAL TO OPEN	3/8 NPT   TSO-C76
SA5817-4C	CCA-1200   3/4"-16 BULKHEAD	7/16"-20   TSO-C76
F50	CCB-38000   CCA-38001 INCLUDED	1/2 NPT   FAA-PMA
F50-180	CCA-38001	
F62	CCB-32000   CCA-38001 INCLUDED	5/8"-18   PMA PENDING
P5000	CCB-5000	1/2 NPT   FAA PMA
S6250	CCB-6250	5/8"-18   FAA PMA
M12175	CCA-2450	12-1.75mm
S5020J	CCA-2460	1/2"-20
M1290B	CCA-2470	ADAPTER
S5090B	CCA-2480	ADAPTER
RM12175	CCA-2474	12-1.75mm
CAV-110H-4	CCA-110-H4	1/8 NPT   TSO-C76 Pending
CAV-160H-4	CCA-160-H4	1/4 NPT   TSO-C76 Pending
CAV-170H-4	CCA-170-H4	7/16"-20   TSO-C76 Pending
CAV-180H-4	CCA-180-H4	3/8"-24   TSO-C76 Pending

\* All applications sourced from available manuals. It is the responsibility of the installer to verify fit and function of all valve information supplied in this guide.